



HIGH PERFORMANCE COMPOSITES

2562 Ridle Run Road Tarentum, Pa 15084

www.smoothline.com

HIGHEST QUALITY WORLD WIDE

♦ Sports Car Hardtops

♦ Sports Car Body Panels

Phone: 724-274-6002

Fax: 727-274-6121

## Datsun 2000 Hardtop High Windshield Installation Instructions

You have just purchased the finest Hardtop available on the market today. Skilled craftsmen using highest quality materials and modern technology have manufactured this product. By following these simple instructions you will have many years of enjoyment and the top will last as long as your car.

The following tips will be helpful if you are qualified to do it yourself. If not, we recommend that your Hardtop be installed and finished by a professional body shop.

A point to remember, automobiles are mass-produced and built with certain tolerance. Sometimes these tolerances are quite large. No two are alike. A body man is a skilled tradesman; a skill that is not learned overnight. A "well fitting" automobile is a series of adjustments and compromises.

### **A: Prior to placing the top on the car**

1. Fold top cloth into the normal down position
2. Clean top of windshield frame and rear deck area  
Lubricate the bottom of the deck rubber of the hardtop with silicone lubricant or other suitable lubricant

### **B Place hardtop on car:**

1. Loosely hook both front fasteners to the windshield frame.
2. On the car cockpit surround, locate a 3/8" hole filled with a rubber plug along the ridge of the rear deck (several inches behind the door on both sides of the car). Remove the rubber plugs, insert the eye bolts down through the holes and reconnect the nuts and washers to the bolt.
3. Hook the rear attachment hooks into the eyebolts. Tighten the rear knobs a little at a time – alternating sides. As you tighten, make sure that the rubber deck molding stays in the proper position. Before finishing the tightening operation, check the alignment of the windows. Shift the rear of the top as necessary to obtain the best alignment.

Continue to tighten the rear fasteners until the rear of the top is completely seated. You may have to pull out the sides of the top to facilitate seating.

4. Trim the side window moldings.
5. Latch the passenger side front fastener by pushing down on the outside right front corner of the top with your right hand while turning the knob with your left hand. Repeat the procedure for the driver's side latch.

### **C. Painting:**

1. Mask off the rear window with cellophane tape or a non-porous material to prevent thinner fumes from attaching the Plexiglas.
2. Mask all rubber. Top is primed with a urethane primer that is compatible with all top coats. No sealer is necessary. Use normal body shop painting procedures.
3. **The factory primed surface must be top coated before being exposed to the weather.** Failure to topcoat over the prime coat can cause blisters or delamination and will void the warranty

### **D. Maintenance of the top:**

1. Side window molding may be lubricated with silicone base wax for easy winding of the windows. Similar lubrication may be use on the deck rubber seal if squeaking occurs.
2. If painted, keep surface waxed to preserve the gloss finish. On vinyl tops, clean periodically with a vinyl cleaner and coat the top with sealer.
3. The rear window is Plexiglas and caution should be exercised to prevent scratching. Clean with mild soap and a sponge or soft cloth. Dry with a chamois skin (keep dirty rags away from the rear window). A plastic wax such as "Mirror Glaze" Can be used to wax the window.
4. Rubber should be treated periodically with a rubber conditioner.

**Warranty:** All Smooth Line Hardtops are warranted to be free from defects in material or workmanship and are warranted for one (1) year from date of purchase. Smooth Line will, at its discretion, repair or replace at its factory, without cost, any part that fails in service, upon our inspection, within the warranty period. The warranty does not cover freight, labor, failure of related components or failure resulting from alteration, misuse, accident damage, faulty installation, color coating, or faulty repair. For warranty service for a Hardtop purchased from a distributor you must make all arrangements through that distributor. If purchased directly from Smooth Line contact Smooth Line sales department. Warranty for all components must be supported by the proper registration documentation including the original shipping invoice. At no time are Smooth Line Hardtops returnable for credit or refund for any reason.

**Returned Goods:** Written authorization must be obtained from Smooth Line and the distributor before merchandise may be returned for warranty service. All merchandise must be properly packaged in non damaged condition. An itemized packing slip, showing invoice number and date, with full explanation of reason for return must be included. All returns must be sent freight prepaid. All costs relative to a return are not reimbursable.

**Freight Damage:** Smooth Line products are carefully packaged by professionals. Delivery in good condition is the responsibility of the carrier. All shipments are insured. Upon receiving your merchandise, while in the presents of the delivery driver, before signing, carefully inspect carton for damage or rough handling. If apparent, open package and inspect merchandise. If damaged, refuse shipment, have driver note damaged on bill of lading. Call Smooth Line after driver leaves with the shipment.

The above terms and conditions pertain to all orders and will be strictly applied. Please do not ask for exceptions.

**WARNING**

This product is designed to enhance the appearance of the vehicle and to shield the occupants from ordinary weather conditions. Do not rely in any way on the components of this product to contain occupants within the vehicle, or to protect against injury or death in the event of an accident. This product will not protect the occupants from falling objects.

**WEAR SEAT BELTS AT ALL TIMES.**